












SOJAG











produits saisonniers • seasonal products







QUESTIONS? 03.28.14.59.46




Assembly Manual / Guide d'assemblage / Manual de ensamblaje / Montageanleitung





V X 240 (+10) 	X X 32 (+3) 	
X1 X 40 (+6) 	Y1 X 44 (+5) 	
Wa X 1 	Z X 1 	
K X 1 	K1 X 1 	
N X 4 	N1 X 4 	N2 X 4 
O X 4 	O1 X 4 	O2 X 4 




D X4 	I X4 		
J X4 	M1 X4 	M2 X8 	
M3 X8 	M4 X8 	Q X 48(+3) optional 	Q X 48(+3)optional  
Net X4   optional	Curtain X4   optional		







M1x4








Ax4







Vx16



























Vx8





Kx1



Wax1

